

**ME7 immo off
(1+4+5)**



**ME7 immo on
(2+4+5)**



**Tdi EDC16 K-line
immobilizer off (3)**



**Tdi EDC16 K-line
immobilizer on (1 + 3)**



**Tdi EDC16 CAN
1.9 - 2.0 immobilizer off
(1 + 3 + 5)**



**Tdi EDC16 CAN
1.9 - 2.0 immobilizer on
(2 + 3 + 5)**



**Tdi EDC16 CAN
2.7-3.0 immobilizer off
(1 + 2 + 3 + 5)**



**Tdi EDC16 CAN
2.7-3.0 immobilizer on
(4 + 5)**



**Tdi EDC15 immobilizer off
(2)**



**Tdi EDC15 immobilizer on
(1 + 2)**



Jeżeli chcemy włączyć zapłon przy elektronicznej stacyjce to łączymy w OBD2 piny 1 i 16

If we want to turn on the ignition in electronic ignition switch, then we must connect in OBD2 pin 1 with 16