

MASK SETS by Autotronika.txt

MASK/SETS	REPLACEMENT	TYPE
B22AN	EEPROM	93C06
B34AB	EEPROM	24C02
B42AB	EEPROM	93C06
B43AB	EEPROM	24C02
B44AF	EEPROM	24C02
B46AJ	EEPROM	24C02
B49AJ	EEPROM	24C02
B52AP	EEPROM	24C02
B54AH	EEPROM	24C02
B81AB	EEPROM	93S66
B56022	EPROM	27C128
B56240		LM2902
B57120	EEPROM	27C64
B57306		80C52
B57324	EEPROM	2732A
B57325	EEPROM	27C32
B57345		ULN2003
B57347	EEPROM	27C64
B57383		CA139EX
B57402		LM2904
B57416		80C49
B57422		74HC74
B57423	EEPROM	27C256
B57425		CD40106
B57427	A/D CONVERTER	ADC0809
B57440	TWO TIMERS	B556
B57449		74HC74
B57477	EEPROM	27C64
B57487		74HCT573
B57496		LM2902
B57498		LM2904
B57515		80C52
B57519	EEPROM	27C64
B57528		SAE81C52
B57545		LM2903
B57546	EEPROM	27C010
B57549		74HC365
B57554		LM2903
B57574		74HCT573
B57558		74HCT00
B57560		74HCT02
B57574		74HCT373
B57581		74HC573
B57582		LM2903N
B57604	EEPROM	27C256
B57605	EEPROM	27C256
B57607	EEPROM	27C128
B57610	EEPROM	27C128
B57618	EEPROM	87C257
B57618	EEPROM	27C64
B57622		80C52
B57625	EEPROM	2764A
B57647		8253
B57648		80C52
B57654	EEPROM	27C256
B57656	MCU	80C535
B57669	EEPROM	24C02
B57677		BD206M
B57684	EEPROM	27C256
B57696	EEPROM	27C256
B57701	EEPROM	27C256
B57725		TA13255A
B57764	EEPROM	87C257
B57764	EEPROM	87C64
B57769	MOTOROLA	MC68HC05SR3
B57771	EEPROM	27C256

MASK SETS by Autotronika.txt

B57781	EEPROM	27C256
B57808	EEPROM	27C256
B57820		TI948B
B57826	RAM	HM6264
B57828		80C515
B57856	EEPROM	28C64
B57922	EEPROM	87C257
B57945		87C52
B57956		TAA765A
B57960	EEPROM	27C256
B57965		74HC14
B57984	EEPROM	27C512
B57995	EEPROM	TMS27C256
B58007		SAB80C517
B58010	RAM	HM6264
B58014	EEPROM	27C256
B58024		80C515
B58029		CA3272
B58038	EEPROM	27C256
B58081		74HCT573
B58090		74HCT573
B58094	EEPROM	27C510
B58097	EEPROM	93C46
B58098	EEPROM	27C512
B58115	RAM	HM6264
B58126	EEPROM	27C010
B58127	EEPROM	27C512
B58150	EEPROM	87C257
B58157	EEPROM	27C512
B58185	EEPROM	87C257
B58196	EEPROM	NS93C46
B58213	EEPROM	93C06
B58214	EEPROM	27C256
B58221	EEPROM	93C46
B58234	EEPROM	27C256
B58235	EEPROM	87C257
B58239	EEPROM	27C512
B58243		CJ87BC6QG
B58244		I87M12
B58252	EEPROM	24C02
B58253	EEPROM	24C02
B58256	EEPROM	24C01
B58258	EEPROM	24C02
B58265	CONTROLLER CAN	Contro1ler
B58271	EEPROM	93C46
B58275	EEPROM	27C1024
B58283	EEPROM	24C02
B58286	CONTROLLER	SAB80C166
B58293	EEPROM	27C512
B58298		80C515
B58323	EEPROM	93C46
B58328	EEPROM	24C02
B58331	EEPROM	28F010
B58334	EEPROM	28C64
B58335	EEPROM	AT28C64B
B58339	FLASH EPROM	28F512
B58379	EEPROM	24C16
B58380	EEPROM	24C02
B58381	FLASH EPROM	28F512
B58383	EEPROM	24C02
B58399	FLASH EPROM	29F010
B58400	EEPROM	87C510
B58424	EEPROM	27C512
B58444	EEPROM	27C010
B58468		SAB80C517
B58470		80C535
B58474		SAB80C517
B58484		SAB80C517

MASK SETS by Autotronika.txt

B58502	ABS, ASR SYSTEM	IC TLE5200G, TLE6210G
B58504	ABS, ASR SYSTEM	IC TLE5201G, TLE6211G
B58517	FLASH EPROM	27C020, 27C2001
B58530	FLASH EPROM	27C010, 28F010, 29F010
B58533	EEPROM	27C4096
B58539	EEPROM	27C256
B58541	EEPROM	27C512
B58542	EEPROM	27C512
B58543	EEPROM	27C512
B58544	EEPROM	27C1001
B58545	EEPROM	87C257
B58546	EEPROM	87C510
B58547	EEPROM	27C1001, 27C010
B58548	EEPROM	TMS27PC210, 27C1024
B58550	EEPROM	27C512
B58553		SCL4410
B58590		AS87C196EN
B58601	FLASH EPROM	29F200B
B58608	EEPROM	93C66
B58637	4xLOW-SIDE SWITCH	TLE5226G, TLE6216G
B58639	EEPROM	87C510
B58647		87C257
B58676		SAF-C509
B58715		SAK-C167
B58717	EEPROM	27C256
B58718	EEPROM	27C512
B58732	4xLOW-SIDE SWITCH	TLE5216G, TLE6220
B58748		SAB83C166
B58755	FLASH EPROM	29F200
B58768	FLASH EPROM	29F400AB
B58791	FLASH EPROM	29F200AB
B58813	EEPROM	93C56
B58838	EEPROM	27C256
B58911	EEPROM	27C010A
B58944		uPD43256BGU-70
B9411	EEPROM	AM27C256
A20T	MOTOROLA	MC68HC705S3
A21T		
A38P	MOTOROLA	MC68HC11A1 or A8
A46E	MOTOROLA	MC68705R3CS
A49N	MOTOROLA	MC68HC11A1 or A8
A58P	MOTOROLA	MC68HC05C8A
A75H	MOTOROLA	MC68HC811A2
B16B	MOTOROLA	MC68HC805C4
B19C	MOTOROLA	MC68HC811E2
B35F	MOTOROLA	MC68HC11A0
B36T	MOTOROLA	MC68HC805B6
B38E		DSP56001
B39P		DSP56001
B43T		
B46E	MOTOROLA	MC68HC11A1 or A8
B60R	MOTOROLA	MC68HC11E1 or E9
B65H	MOTOROLA	MC68HC11A8
B71N		
B76T	MOTOROLA	MC68HC11Ax or Ex
B77G		DSP56001
B77M	MOTOROLA	XC68HC11F1
B83T	MOTOROLA	MC68HC05B8
B84N	MOTOROLA	MC68HC11A1
B84T	MOTOROLA	MC68HC11A1
B87N	MOTOROLA	MC68HC05C4
B88T		
B89N	MOTOROLA	MC68HC000
B91T	MOTOROLA	MC68HC05B6
B95T	MOTOROLA	MC68HC11A0 or A1
B96D	MOTOROLA	MC68HC11A0 or A1
B96T	MOTOROLA	MC68HC05C8
C10C	MOTOROLA	MC68HC05M4

MASK SETS by Autotronika.txt

C11W	MOTOROLA	MC68HC11A1
C12R	MOTOROLA	MC68882FN20A
C13W	MOTOROLA	MC68HC11L6
C14H	MOTOROLA	MC68HC05B6
C15J	MOTOROLA	MC68HC11F1
C16J	MOTOROLA	MC68HC811E2
C16W	MOTOROLA	MC68HC705C8
C17F	MOTOROLA	MC68HC11D3
C21T		DSP56001
C25T	MOTOROLA	MC68HC05E1
C27B	MOTOROLA	MC68HC11E1
C27T	MOTOROLA	MC68HC05P8
C28M	MOTOROLA	MC68HC11G5FN1
C28W	MOTOROLA	MC68HC05P9
C32K		MC44000P
C35N	MOTOROLA	MC68HC05B16
C40H	MOTOROLA	MC68HC05J1
C45A	MOTOROLA	MC68HC711D3
C46A	MOTOROLA	XC68HC811A8
C47M	MOTOROLA	MC68HC711E9
C61A	MOTOROLA	MC68HC05P
C68S		DSP56001
C83W	MOTOROLA	MC68HC11E9
C85W	MOTOROLA	MC68HC711L6
C90T	MOTOROLA	MC68HC05P8
C91F	MOTOROLA	MC68HC11E1
C92K	MOTOROLA	MC68HC05C12A
C93W	MOTOROLA	XC68HC711K4
C94R	MOTOROLA	MC68HC11F1
C95K	MOTOROLA	MC68HC05E0
C96K	MOTOROLA	MC68HC11E9
C96N	MOTOROLA	MC68HC11E9 or MC68HC11A1
C99K	MOTOROLA	MC68HC05B4
D10J	MOTOROLA	MC68HC705B5
D12A	MOTOROLA	MC68B09EP
D13N		DSP56156
D15G	MOTOROLA	MC68HC05E1
D17E	MOTOROLA	MC68HC05T3
D18E	MOTOROLA	MC68HC05P4
D20J	MOTOROLA	MC68HC05B16
D20K		MC44000P
D25A	MOTOROLA	MC68HC05P4
D26E	MOTOROLA	MC68HC11A0 or A1
D28J	MOTOROLA	MC68HC705B16
D28N	MOTOROLA	MC68HC05E6
D28T	MOTOROLA	MC68HC705F6B
D32N	MOTOROLA	MC68HC705E1
D32N1	MOTOROLA	MC68HC05E1
D33J	MOTOROLA	MC68HC05B8
D35E	MOTOROLA	MC68HC11E9
D37G		DSP56002
D37R	MOTOROLA	MC68HC05C12A
D40G		DSP56004
D40J	MOTOROLA	MC68HC705B32, MC68HC705X32
D41G		DSP56002
D41V	MOTOROLA	MC68HC705BE12
D43F	MOTOROLA	MC68HC11K4
D43R	MOTOROLA	MC68HC711E20
D44G		DSP56002
D45R	MOTOROLA	MC68HC11ED0
D46J	MOTOROLA	MC68HC711EA9
D47J	MOTOROLA	MC68HC11EA9
D48A	MOTOROLA	MC68HC05H2
D48J	MOTOROLA	MC68HC11PH8
D49R		
D51D	MOTOROLA	MC68HC05P8
D53J	MOTOROLA	MC68HC05X32
D54E	MOTOROLA	MC68HC705P9

MASK SETS by Autotronika.txt

D54J	MOTOROLA	MC68HC05B8
D56G	MOTOROLA	MC68HC705P6ACDW
D58J	MOTOROLA	MC68HC11PA8
D58N	MOTOROLA	MC68HC11K1
D59J	MOTOROLA	MC68HC705B32, MC68HC705X32
D60J	MOTOROLA	MC68HC05B16
D61N	MOTOROLA	MC68HC711KA4
D62C	MOTOROLA	MC68030FE20B
D62J	MOTOROLA	MC68HC05X16
D63F		
D64J	MOTOROLA	MC68HC(7)11PH8
D67F	MOTOROLA	MC68HC711K4
D67P	MOTOROLA	MC68HC05C8
D68C	MOTOROLA	MC68HC705C5
D69F	MOTOROLA	PC68HC711N4
D69J	MOTOROLA	MC68HC05X32
D73W	MOTOROLA	MC68HC705G10
D82R	MOTOROLA	MC68HC11E9
D84M	MOTOROLA	MC68HC05H2
D85F	MOTOROLA	MC86HC711D3
D86B	MOTOROLA	MC68HC705J2
D89T		DSP56156
D99H	MOTOROLA	MC68HC711P2
E11P	MOTOROLA	MC68HC16Z2
E13G		68EC020
E17T		DSP56166
E19K		DSP56166
E20T	MOTOROLA	MC68HC705C4A or C8A
E20Y	MOTOROLA	MC68HC705P6CP
E22B	MOTOROLA	MC68HC11E20
E23D		
E25B	MOTOROLA	MC68HC05P3
E25H		DSP56156
E25S		DSP56156
E28B	MOTOROLA	MC68HC11E1 or E9
E30A	MOTOROLA	MC68HC05K1
E30G		68020
E31A	MOTOROLA	MC68HC05K0
E31M	MOTOROLA	MC68HC705K1
E32A	MOTOROLA	MC68HC705P6
E32B	MOTOROLA	MC68HC05C8
E36F	MOTOROLA	MC68HC05C8
E38B	MOTOROLA	MC68HC05J3
E40A	MOTOROLA	MC68HC705C5
E41C	MOTOROLA	PC68HC916Y1
E41J		MC68060
E41R		68341
E42K		68040
E43B		DSP56004
E44B		DSP56002
E45H		DSP56166
E46B		DSP56002
E50H	MOTOROLA	MC68HC05B16
E50W	MOTOROLA	MC68HC711E9
E52N		DSP56166
E53M	MOTOROLA	MC68HC711P2
E54F	MOTOROLA	MC68HC16Z1
E57S	MOTOROLA	MC68HC11KA4
E59B	MOTOROLA	MC68HC11KA4
E61H	MOTOROLA	MC68HC11F1
E61R	MOTOROLA	MC68HC705C8
E61W	MOTOROLA	MC68HC705F8
E62H	MOTOROLA	MC68HC11K4
E62W	MOTOROLA	MC68HC16Z1
E68C		68360
E69A		DSP56156
E69W	MOTOROLA	MC68HC16Z1PV16
E71M		68EC/LC040

MASK SETS by Autotronika.txt

E72N	MOTOROLA	MC68HC000
E74J	MOTOROLA	MC68HC11P2
E75J	MOTOROLA	MC68HC11K4
E75N	MOTOROLA	MC68HC05C8A
E78C	MOTOROLA	MC68HC05J1A
E79R	MOTOROLA	MC68HC705C8A , C4A
E82K	MOTOROLA	MC68HC11E20
E84R		SC428492FA
E87J	MOTOROLA	MC68HC11F1
E88N	MOTOROLA	MC68HC711KA2
E94M		68306
E98K	MOTOROLA	MC68HC705P6
E98S		DSP56156
F10V	MOTOROLA	MC68HC05B6
F10W	MOTOROLA	MC68HC705SR3
F11N	MOTOROLA	MC68HC11L6
F12A	MOTOROLA	MC68HC05J1A
F13C		68349
F17V	MOTOROLA	MC68HC11F1B4
F19C	MOTOROLA	MC68EC030CFE25C
F21P		68HC901
F21S	MOTOROLA	MC68HC705MC4
F22A		DSP56156
F23H	MOTOROLA	MC68HC05P4A
F25W	MOTOROLA	MC68HC11MA8
F26E		68302
F28A		DSP56166
F28B	MOTOROLA	MC68HC05E6
F29K	MOTOROLA	MC68HC11MA8
F33P	MOTOROLA	PC68HC16V1
F37E	MOTOROLA	MC68HC11F1
F41E	MOTOROLA	MC68HC05L28
F41J	MOTOROLA	MC68HC05L28
F43G	MOTOROLA	MC68060, MC68LC060, MC68EC060
F44E		DSP56156
F44T	MOTOROLA	MC68HC705J1A
F46E		DSP56002
F48M		DSP56002
F48S		56301
F49K	MOTOROLA	MC68HC705C8A
F52E	MOTOROLA	MC68HC11E32
F52W	MOTOROLA	MC68HC05P18
F53E	MOTOROLA	MC68HC11KG4 or 711KG4
F56K	MOTOROLA	MC68HC705B16
F60M	MOTOROLA	MC68HC11KA4
F62A	MOTOROLA	MC68HC05C8
F62J	MOTOROLA	MC68HC05B16
F63J	MOTOROLA	MC68HC705C9A
F65E		68322
F67V	MOTOROLA	MC68HC16Z1
F68K	MOTOROLA	MC68HC912D60
F71L	MOTOROLA	MC68HC05C8 or 705C8
F73K	MOTOROLA	MC68HC912D60
F73T	MOTOROLA	MC68HC16Z1
F74B	MOTOROLA	MC68HC05X4
F75B	MOTOROLA	MC68HC705P3
F76J		DSP56002
F79B		
F80B	MOTOROLA	MC68HC705P6ACDW
F82B	MOTOROLA	MC68HC705E6
F82W	MOTOROLA	MC68HC705V8
F83B		
F83S		68MH360
F84C		860
F87L		DSP56002
F88B	MOTOROLA	MC68HC705X4
F91C		68030
F91R		DSP56007

MASK SETS by Autotronika.txt

F92J	MOTOROLA	MC68HC11PA1
F96J	MOTOROLA	MC68HC11E9
F97J	MOTOROLA	MC68HC11E9 or MC68HCP11E1
F98S		823
F98Y	MOTOROLA	MC68HC708AS48
G10J		5206
G10V	MOTOROLA	MC68HC(7)11P2
G11D	MOTOROLA	MC68HC16Z2
G23V	MOTOROLA	MC68HC08AZ32
G26C	MOTOROLA	MC68HC16Z3
G28F	MOTOROLA	MC68HC05B16
G32V	MOTOROLA	MC68HC11KG4
G33P	MOTOROLA	MC68HC705P6ACP
G35N	MOTOROLA	MC68HC05B16
G39Y	MOTOROLA	MC68HC08AS20
G40G	MOTOROLA	MC68HC805K3
G40W		68EC030
G41V	MOTOROLA	MC68HC705B32
G44P	MOTOROLA	MC68HC705RC16..17
G47B	MOTOROLA	MC68HC000, 68SEC000
G47V	MOTOROLA	MC68HC705X32
G49V	MOTOROLA	MC68HC08AZ32
G53F	MOTOROLA	MC68HC05J1A
G54K	MOTOROLA	MC68HC05TB
G56P	MOTOROLA	MC68HC705BD7P
G57B		68307
G58C	MOTOROLA	MC68HC705JP7
G58E		68328
G58F	MOTOROLA	MC68HC705J1A
G58T	MOTOROLA	MC68HC705JJ7 or JP7
G59B		68322
G59F	MOTOROLA	MC68HC711E20
G59Y	MOTOROLA	MC68LC060 , MC68EC060
G61B		414277
G61E		56012
G62K	MOTOROLA	MC68HC708AS48
G63P	MOTOROLA	MC68HC705J1A
G64R	MOTOROLA	XC68HC805P18
G65V	MOTOROLA	MC68060, MC68LC060, MC68EC060
G67F		68340
G68P		DSP56156
G71K		68306
G72G	MOTOROLA	MC68HC05E6
G73K	MOTOROLA	MC68HC000
G74K	MOTOROLA	MC68HC000, 68EC000
G76K	MOTOROLA	68HC681
G78K	MOTOROLA	MC68HC000, MC68EC000, 68SEC000
G78M	MOTOROLA	MC68HC705V12
G79C		
G85K		414294
G94F		XCF5202
G96A	MOTOROLA	MC68HC705B32
G96Y	MOTOROLA	MC68HC705V12
G97K		414339
H11H		414362
H14A	MOTOROLA	MC68HC708AS48
H14N		5204
H18H		414361
H19S	MOTOROLA	MC68HC711E20
H20D		5204
H24A	MOTOROLA	MC68HC11A8
H24M	MOTOROLA	MC68HC05V12
H27B	MOTOROLA	MC68HC711KS2 or 711KA2
H30H		56009
H30R	MOTOROLA	MC68HC11PH8
H32S	MOTOROLA	MC68HC705JB4
H37T		68340
H39G		5307

MASK SETS by Autotronika.txt

H42D	MOTOROLA	MC68HC05V12
H42K	MOTOROLA	MC68HC705C8A
H44H	MOTOROLA	MC68HC805P18 or MC68HC05BS8
H48T	MOTOROLA	XC68CM16Z1
H50F	MOTOROLA	MC68HC812AV4
H50W	MOTOROLA	MC68HC711E9
H51K		68328
H52A	MOTOROLA	MC68HC05X32
H52P	MOTOROLA	MC68HC705V12
H54T	MOTOROLA	MC68HC12BE32
H55B	MOTOROLA	MC68HC705BD9
H55F	MOTOROLA	MC68HC805K3
H55J		5307
H55W	MOTOROLA	MC68HC912DG128, DA128
H56A	MOTOROLA	MC68HC08AZ32
H57A	MOTOROLA	MC68HC05H12
H58B		68328
H62A	MOTOROLA	MC68HC908AS60 or AZ60
H62P	MOTOROLA	MC68HC908AT32
H70G		56004
H70H	MOTOROLA	MC68HC705SJ7 or JJ7 or JP7 or SP7
H72J	MOTOROLA	MC68HC705C8A
H73K	MOTOROLA	MC68HC812AV4
H74P		68EN302
H74Y	MOTOROLA	MC68HC08AZ60A
H75A	MOTOROLA	MC68HC705P6ACDW
H75D		XCF5202
H76G		56362
H77A	MOTOROLA	MC68HC705C9A
H78X	MOTOROLA	MC9S12H256VfV
H82G		56303
H86A	MOTOROLA	MC68HC711KG2
H86X	MOTOROLA	MC68HC(7)11KG2 ??
H89E	MOTOROLA	MC68HC11E20
H89G		823/850
H91F	MOTOROLA	MC68HC912B32
H94K	MOTOROLA	MC68HC08AS20
H95B	MOTOROLA	MC68HC11KA4
H96J	MOTOROLA	MC68HC05JJ6, JP6
H98X	MOTOROLA	MC68HC11KS8
HETY3	MOTOROLA	MC68HC05Bxx
J15G	MOTOROLA	MC68HC912BC32
J17A		68360
J20X	MOTOROLA	MC68HC908GP32
J21C		414355
J22A		56303
J22G		5206e
J24A		860
J26H	MOTOROLA	MC68HC08AS20
J26R	MOTOROLA	MC68HC08AS20
J27F	MOTOROLA	MC68HC08AS32
J29A		68EC/LC302
J30C		68332TSG
J33R		
J34P	MOTOROLA	MC68HC12BE32
J35D	MOTOROLA	MC68HC08AZ60
J37F	MOTOROLA	MC68HC908MR24
J38M	MOTOROLA	MC68HC12BE32
J41C	MOTOROLA	MC68HC05SU3A
J43F	MOTOROLA	MC68HC705V12
J43H	MOTOROLA	MC68HC705V12
J52E		56007
J53W	MOTOROLA	MC68HRC705JP7CDW
J54E	MOTOROLA	MC68HC912B32
J54W	MOTOROLA	MC68HRC705JP7CDW
J56W		MMC2001 or 2003
J61D	MOTOROLA	MC68HC908AS60
J64Y	MOTOROLA	MC68HC912B32

MASK SETS by Autotronika.txt

J66D	MOTOROLA	MC68HC08AZ32
J66H	MOTOROLA	MC68HC705J1A
J73R	MOTOROLA	MC68HC705C8A
J74Y	MOTOROLA	MC68HC908AS60 or AZ60
J75C	MOTOROLA	MC68EZ328CE
J79Y	MOTOROLA	MC68HC908BD48
J82M	MOTOROLA	MC68HC000
J83G	MOTOROLA	MC68EZ328
J88Y	MOTOROLA	MC68HC908JK3 , MC68HC908JL3ECP
J89C		414379
J89E		56009
J94M	MOTOROLA	MC68HC000
K00J	MOTOROLA	MC68HC908RK2
K00W	MOTOROLA	MC68HC11K4
K02S	MOTOROLA	MC68HC05P4A
K03B	MOTOROLA	MC68HC705C9A
K05W	MOTOROLA	MC68HC711D3
K07B	MOTOROLA	MC68HC705P6ACDW
K07E	MOTOROLA	MC68HC11KS2
K08B	MOTOROLA	MC68HC705C8A
K08S	MOTOROLA	MC68HC908GP32
K08W	MOTOROLA	MC68HC711KS2
K11N	MOTOROLA	MC68HC908LD64
K13J	MOTOROLA	MC68HC12D60 or 912D60
K20C	MOTOROLA	MC68HC705B32
K20R	MOTOROLA	MC68HC05PV8A
K20W	MOTOROLA	XC510164CF
K22K		MMC2001 or 2003
K25E	MOTOROLA	MC68HC912BC32
K29E	MOTOROLA	MC68HC912BD32
K31D	MOTOROLA	MC68HC912DG128A
K36N	MOTOROLA	MC9S12DP256
K38K	MOTOROLA	M68HC912D60
K39K	MOTOROLA	MC68HC908SR12
K45D	MOTOROLA	MC68HC908KX8, KX2
K45H	MOTOROLA	MC68HC908JB8
K50E	MOTOROLA	MC68HC912DG128, DA128
K54X	MOTOROLA	MC68HC711K4
K56G	MOTOROLA	MC68HC908AB32
K59D	MOTOROLA	MC68HC08JB8
K59H		PC527283MFU
K71E	MOTOROLA	MC68HC08AS32
K75F	MOTOROLA	MC68HC912D60
K76A	MOTOROLA	MC68HC12DA128
K78X	MOTOROLA	MSE9S12H256, MC9S12H256
K79X	MOTOROLA	MSE9S12D256B, MC9S12DP256 or A256 or DG256B or
DJ256B		
K81H	MOTOROLA	MC68HC711E9
K82H	MOTOROLA	MC68HC11E20
K85K	MOTOROLA	MC68HC908AZ60A or AS60A
K85V	MOTOROLA	MC68HC908AZ60A
K91D	MOTOROLA	MC68HC912DG128
L00M	MOTOROLA	MSE9S12DP512, MC9S12DP512
L01Y	MOTOROLA	MSE9S12DT256
L02H	MOTOROLA	M68HC912D60
L02M	MOTOROLA	MC68HC08AZ48A
L05H	MOTOROLA	M68HC912DT128
L06H	MOTOROLA	MC68HC908SR12
L08M	MOTOROLA	MSE9S12E128
L09H	MOTOROLA	MC68HC908KX8 or KX2
L09S	MOTOROLA	MSE9S12C128 or MC9S12C96
L15P	MOTOROLA	MSE9S12E128
L15Y	MOTOROLA	MC9S12XDP512V2 or MSE9S12XDP512
L16Y	MOTOROLA	MSE9S12HZ256
L19E	MOTOROLA	MC68HC908JL3ECP
L19S	MOTOROLA	MSE9S12NE64
L24K	MOTOROLA	MSE9S12T64
L24N	MOTOROLA	MSE9S12UF32

MASK SETS by Autotronika.txt

L26M	MOTOROLA	MC68HC912D60
L27M	MOTOROLA	MC68HC912DG128
L28M	MOTOROLA	MC68HC12D60
L31K	MOTOROLA	MC68HC08JL3E
L31V	MOTOROLA	MC68HC908AS60A or AZ60A
L32X	MOTOROLA	MC68HC08AZ32A
L33V	MOTOROLA	MSE9S12KT256
L35K	MOTOROLA	MC68HC08
L35X	MOTOROLA	MC68HC08JL3E
L36W	MOTOROLA	MC68HC908JL3E
L39J	MOTOROLA	MC68HC908JL8
L40K	MOTOROLA	MSE9S12DT128, MC9SDG128E
L40V	MOTOROLA	MSE9S12XDP512
L40X	MOTOROLA	MC68HC08AZ60A
L42M	MOTOROLA	MSE9S12T64
L43P	MOTOROLA	MSE9S12DG64
L43X	MOTOROLA	MSE9S12E256
L45J	MOTOROLA	MC9S12C32 or MSE9S12C32
L45N	MOTOROLA	MC9328MXL
L47P	MOTOROLA	MSE908AP64
L47S	MOTOROLA	MSE9S12UF32
L50P	MOTOROLA	M68HC908GR48A
L51J	MOTOROLA	M68HC912D60
L51W	MOTOROLA	MC68HC908SR12
L52H	MOTOROLA	MC68HC08AZ32A
L53J	MOTOROLA	MC68HC908GR8
L54J	MOTOROLA	MC68HC908MR32 or 16
L59W	MOTOROLA	MSE9S12DT128
L59X	MOTOROLA	MC68HC908AB32
L61N	MOTOROLA	MC68HC08JL8
L69J	MOTOROLA	MC68HC908QT1-4 or QY1-4
L69Y	MOTOROLA	MC68HC08JL8
L74N	MOTOROLA	MSE9S12KG128
L77N	MOTOROLA	MC68HC908JL3E or JK3E or JK1E
L80P		
L80R	MOTOROLA	MSE9S12B128
L85D	MOTOROLA	MSE9S12DT128, MC9S12A128 or DTB128
L86C	MOTOROLA	MSE9S12T64
L86D	MOTOROLA	MC9S12D64, MSE9S12DG64
L87J	MOTOROLA	MC68HC908AZ60A or AS60A
L91N	MOTOROLA	MC9S12DP256B or MSE9S12DT256
L94R	MOTOROLA	MSE9S12DT128
L96S	MOTOROLA	MC68HC908GP32
M21A	MOTOROLA	MSE9S08RE16
M22E	MOTOROLA	MSE9S12XEP100
M25D	MOTOROLA	MSE908AP64
M34C	MOTOROLA	MSE9S12C32
M42E	MOTOROLA	MSE9S12XDG128
M65G	MOTOROLA	MSE9S12B128
M66G	MOTOROLA	MSE9S12C128
M89C	MOTOROLA	MSE9S12DG64